









GB	Quick user guide
FR	Mini-guide de l'utilisateur
DE	Kurzanleitung
NL	Beknopte handleiding
IT	Guida veloce
ES	Guía rápida de usuario
PT	Guia rápido do Utilizador
PL	Krótki podręcznik użytkownika
RU	Краткое руководство пользователя
SE	Snabb bruksanvisning
NO	Hurtigguide
DK	Hurtig brugervejledning
FI	Pikaopas
ID	Panduan cepat untuk pengguna
CN	便捷用户指南 دليل الاستخ دام السري ع



Key Lock



M10



12 mm



17 mm




Chubb safes

Trusted the world over.











<http://www.chubbsafes.com>

'Chubb' is owned by Chubb plc and is a registered trademark used under license



GB The safe must be anchored when in use.
 FR Le coffre doit être ancré.
 DE Wenn der Safe verwendet wird, muss er verankert sein.
 NL De kluis moet tijdens gebruik verankerd zijn.
 IT La cassaforte deve essere fissata durante l'uso.
 ES La caja debe anclarse al usarla.
 PT O cofre tem de encontrar-se fixado quando em utilização.
 PL Sejf jeżeli jest używany musi być zamocowany.

RU Сейф должен быть укреплен перед использованием.
 SE Kassaskåpet måste vara förankrat när det används.
 NO Safen må være forankret når den er i bruk.
 DK Pengeskabet skal være fastgjort, når det er i brug.
 FI Kassakaapin on oltava käytön aikana kiinnitetty.
 ID Pengaman harus ditanamkan pada saat digunakan.
 CN 使用中的保险柜必须固定在某个位置。
 يجب أن تكون الخزنة ثابتة أثناء الاستخدام.



Chubbsafes
Trusted the world over.

<http://www.chubbsafes.com>

'Chubb' is owned by Chubb plc and is a registered trademark used under license