


KEYSECURITYBOX

solid as a rock

KS007xl

Installation in a wall with inner safe and slide

User manual English



Specifications

Model: KSB 007xl

Dimensions safe: 215 x 555 x 177 mm

Dimensions façade plate: 200 x 320 x 145 mm

Weight: 24 kg

Colour: RAL 9006

Box content KSB 007

- 1 x KeySecurityBox
- 1 x Slide
- 1 x floor mat for in the safe
- 1 x covering plate
- 4 x Ring Ø 20 mm
- 4 x thread end
- 4 x Nut M10
- 1 x instruction sticker
- 2 x safe keys

You will need the following for installation (not included)

- Measure
- Pencil/pen
- Spirit level
- hammer drill with drill and chisel
- angle grinder with diamond cutter and metal grinding plate
- Spanner/wrench
- Hammer and chisel

Congratulations on choosing our ultra-reliable KeySecurityBox, the ideal solution for keys and keycards. The KeySecurityBox is extremely durable and, thanks to the range of models, there's always a solution to meet your need.


You have chosen the KSB 007xl, intended for installation in a wall, with an inner safe and slide.

Note: before you start, make sure you are not installing the safe in a place with pipe in the wall or where you are interfering with the load-bearing construction. If you are in doubt consult a construction advisor.




1

Determine where you want to place the safe. Make sure there is enough room for the façade plate and the inner safe. Also take account of pipes and other construction limitations.



2

The wall thickness shown is 30 centimeters. You can also place the safe in a thinner or thicker wall (see table). Draw the four drilling holes for the thread ends that are going to pass through the wall. Drill the holes ($\varnothing 16$ mm) horizontally through the whole wall. The holes have to be the same size inside so that the thread ends exit properly into the holes of the inner safe.



NB1 For walls thinner than 14 centimeters you will need to make the inner wall thicker, for example by placing a multiplex panel.



NB2 For walls thicker than 34 centimeters you will have to make some alterations, whereby the inner safe will be placed lower than the façade plate. Please use the KSB007xl Lowering bracket and follow the user manual as supplied.

NB3 For a sandwich panel, a stainless steel/inox plate (450x450x3 mm) will have to be applied between the façade plate and the outer wall. Fill the space in the wall with wood (multiplex). If necessary strengthen the inner wall with a multiplex panel between the wall and the inner safe.



3

Make a recess of 150 x 230 x 143 mm (bxhxd) in the outer wall to hold the façade plate/roll (140 mm deep). The lower incision must face downwards at an angle. Turn the thread ends into the sleeve of the façade plate. Push them through the wall. Draw on the thread ends so that once you have sawn them off they still stick out by 3 centimeters.




4


Temporarily place the inner safe over the thread ends and attach with two nuts (make sure the façade plate does not fall out of the wall and is getting damaged!). On the wall draw the recess for the hole of the slide. Ensure that there is a slope of at least 30°. Place the lowering set (optional item) if the wall is thicker than 30 centimeters, so that there is a gradient of at least 30°. Then determine the length of the slide and if necessary grind a piece off with the angle grinder.




- 5** Place the façade plate, inner safe and adjusted slide. Ensure that the security pins on the facade plate hook into the slot of the slide. Place the rings and nuts on the thread ends. The covering plate in the inner safe goes on the lower thread ends, and the slide sticks out slightly through the hole. Secure the slide with the locking plate on the covering plate. Place the plastic mat on the bottom of the safe.




- 6** Place the instruction sticker in the middle above the deposit wheel.





Optional

Place the lowering set if the wall is thicker than 30 centimeters, so that there is a gradient of at least 30°



Optional


Place the stainless steel rain / anti-masking cover to prevent rain and masking.

Maintenance

Regularly check whether the drainage holes on the bottom of your KeySecurityBox are open and whether all the bolts are still solid and in place. Treat for possible rust.

Questions?

Ask your supplier



Disclaimer with respect to installation, breakage and theft

The manufacturer and vendor of the KeySecurityBox are not liable for the installation. The installation is easy although we recommend you ask a contractor or other professional to do it for you. The KeySecurityBox is intended for depositing keys and keycards and not for paper and other objects that may get stuck in the deposit wheel. The KeySecurityBox is an anti-theft and anti-breakage box, although with excessive violence theft and breakage are possible. The use is therefore for personal risk and the manufacturer and vendor of the KeySecurityBox are not liable for breakage or theft or physical harm caused by its incorrect use.

